

Head Ski Boots Size Chart

Men's Head Ski Boots Size Chart

UK Shoe Size	Mondo (cm)	Euro	US Shoe Size
6	25	39	7
6.5	25.5	40	7.5
7	26	40.5	8
7.5	26.5	41	8.5
8	27	42	9
8.5	27.5	42.5	9.5
9	28	43	10
9.5	28.5	44	10.5
10	29	44.5	11
10.5	29.5	45	11.5
11	30	45.5	12
11.5	30.5	46	12.5
12	31	47	13
12.5	31.5	47.5	13.5
13	32	48	14
13.5	32.5	48.5	14.5
14	33	49	15
14.5	33.5	50	15.5
15	34	51	16

Ladies Head Ski Boots Size Chart

UK Shoe Size	Mondo (cm)	Euro	US Shoe Size
3	22	35	5
3.5	22.5	36	5.5
4	23	36.5	6
4.5	23.5	37	6.5
5	24	38	7
5.5	24.5	38.5	7.5
6	25	39	8
6.5	25.5	40	8.5
7	26	40.5	9
7.5	26.5	41	9.5
8	27	42	10
8.5	27.5	42.5	10.5

Kids Head Ski Boots Size Chart

UK Shoe Size	Mondo (cm)	Euro	US Shoe Size
7	15	25	8
8	16	26	9
9	17	27	10
10	17.5	28	11
11	18.5	29	12
12	19.5	30.5	13
13	20	31	13.5
13.5	20.5	32	1
1	21	33	2
2	21.5	34	3
3	22	35	4
3.5	22.5	36	4.5
4	23	36.5	5
4.5	23.5	37	5.5
5	24	38	6
5.5	24.5	38.5	6.5